

## Device Reader



This tool reads the available features of a device. A visualization shows if a feature is available or not.

## Product Description

This tool reads the available features of a device. A visualization shows if a feature is available or not.

## Range of Functions

The visualization shows an overview of all possible features. Each feature has a status field which turn to green if the feature is available for the active device.

### Available features for the active device

Targetvisu			Sercos III	
Webvisu			Slave	
RemoteVisuClient			Master	
SoftMotion			Profibus	
Basic			Slave	
CNC			Master	
Light			Profinet	
CNC restricted			Slave	
FDT			Master	
CANopen			Ethernet/IP	
Slave			Slave	
Master			Master	
EtherCAT			DeviceNET	
EL6731 Master			Slave	
EL6631 Master			Master	
EL6731-0010 Slave			Redundancy	
EL6631-0010 Device			J1939	
Modbus TCP			EL6900	
Slave			IO-Link	
Master			IEC61850 Server	
Modbus Seriell			BACnet	
Slave			SNMP	
Master			OPC UA	
Single Device License			C-Integration	
Dongle				
Softcontainer				

Visualization 'Device Reader'

## General Information



<b>Supplier</b>	3S-Smart Software Solutions GmbH Memminger Straße 151 87439 Kempten Deutschland
<b>Support</b>	Tel: +49 831 54031 66 support@codesys.com
<b>Product</b>	Device Reader
<b>Order Number</b>	000007
<b>Sales</b>	CODESYS Store store.codesys.com
<b>Scope of Delivery</b>	▪ CODESYS Package with project

## System Requirements and Restrictions

<b>Programming System</b>	CODESYS Development System V3.5.5.0
<b>Target System</b>	CODESYS Control V3.5.5.0
<b>Supported Platforms / Devices</b>	All
<b>Additional Requirements</b>	-
<b>Restrictions</b>	-
<b>Licensing</b>	-
<b>Required Accessory</b>	-